

ISA boards DIP switch settings

The table below indicates the EasyIO Board Dip Switch (SW1) settings:

1	2	3	4	5	6	7	8	I/O Add.
ON	ON	ON	ON	ON	ON	OFF	OFF	200
OFF	ON	ON	ON	ON	ON	OFF	OFF	208
ON	OFF	ON	ON	ON	ON	OFF	OFF	210
OFF	OFF	ON	ON	ON	ON	OFF	OFF	218
ON	ON	OFF	ON	ON	ON	OFF	OFF	220
OFF	ON	OFF	ON	ON	ON	OFF	OFF	228
ON	OFF	OFF	ON	ON	ON	OFF	OFF	230
OFF	OFF	OFF	ON	ON	ON	OFF	OFF	238
ON	ON	ON	OFF	ON	ON	OFF	OFF	240
OFF	ON	ON	OFF	ON	ON	OFF	OFF	248
ON	OFF	ON	OFF	ON	ON	OFF	OFF	250
OFF	OFF	ON	OFF	ON	ON	OFF	OFF	258
ON	ON	OFF	OFF	ON	ON	OFF	OFF	260
OFF	ON	OFF	OFF	ON	ON	OFF	OFF	268
ON	OFF	OFF	OFF	ON	ON	OFF	OFF	270
OFF	OFF	OFF	OFF	ON	ON	OFF	OFF	278
ON	ON	ON	ON	OFF	ON	OFF	OFF	280
OFF	ON	ON	ON	OFF	ON	OFF	OFF	288
ON	OFF	ON	ON	OFF	ON	OFF	OFF	290
OFF	OFF	ON	ON	OFF	ON	OFF	OFF	298
ON	ON	OFF	ON	OFF	ON	OFF	OFF	2A0*
OFF	ON	OFF	ON	OFF	ON	OFF	OFF	2A8
ON	OFF	OFF	ON	OFF	ON	OFF	OFF	2B0
OFF	OFF	OFF	ON	OFF	ON	OFF	OFF	2B8
ON	ON	ON	OFF	OFF	ON	OFF	OFF	2C0
OFF	ON	ON	OFF	OFF	ON	OFF	OFF	2C8
ON	OFF	ON	OFF	OFF	ON	OFF	OFF	2D0
OFF	OFF	ON	OFF	OFF	ON	OFF	OFF	2D8
ON	ON	OFF	OFF	OFF	ON	OFF	OFF	2E0
OFF	ON	OFF	OFF	OFF	ON	OFF	OFF	2E8
ON	OFF	OFF	OFF	OFF	ON	OFF	OFF	2F0
OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF	2F8

*Default